

::: TEAK CARE CLEANER

Description:

Is a liquid cleaner that cleans effortlessly and leaves teak looking like new. Teak Cleaner restores the wood's natural colour.
Available in 500 ml packaging.

Application:

Suitable for cleaning teak furniture and other qualities of wood used in boat building. For stubborn stains, apply 2 to 3 times.

Data on delivery:

| | |
|---------------|--------------------------------|
| Color: | green-blue |
| Viscosity: | not applicable |
| Mass density: | approx. 1.10gr/cm ³ |
| Shelf life: | unlimited |
| Consistency: | liquid |

Technical data:

| | |
|--------------|--------------------------|
| Consumption: | depending on application |
| Shore: | not applicable |

Application:

Shake well before use!

Pre-soak the surface to be treated with water and evenly apply a layer of Teak Cleaner with a brush. Allow to soak in for +-45 minutes. In between, scrub with a hard brush in the direction of the grain. In the meantime, keep the teak moist. Then rinse with plenty of water and allow to dry thoroughly. In case of heavy soiling, repeat the treatment. For a long-lasting protection it is best to treat the wood with SL Clear Teak Oil.

Safety:

Contains oxalic acid. This is harmful in contact with skin and if swallowed. Always wear suitable gloves and protective clothing. If swallowed, seek medical advice immediately and show the label or packaging. Keep out of reach of children. Empty containers should be disposed of in the environmental box. Always make sure the surface is wet. Rinse thoroughly with water. Cleaning agent for tools: water and soap.